

Linkage for Satchwell Valves

MOUNTING INSTRUCTIONS

Linkages components (all the following parts are included in the bag)			Use with valves (models - DN)					MVE.R		
			MVE				VZ/MZ			
			VSF - 15,25 MJF - 20,25 MZ, VZ - 15-50	VSF - 20,32-50 MJF - 15,32-50	VZF MZF 65-100	VZF MZF 125-150				
Q	Position	Description								
1	A*	Neck adapter for 1 3/8"	X	X			X	X		
1	B*	Neck adapter for 1 1/4"			X	X				
1	C	Lock nut for 1 3/8"		X				X		
1	D*	Stem adapter for 1/4" (short L = 55 mm)	X					X		
1	E*	Stem adapter for 1/4" (medium L = 70 mm)		X			X			
1	F*	Stem adapter for 1/4" (long L = 109 mm)			X					
1	G*	Stem adapter for 3/8" (L = 55 mm)				X				
2		M8 nuts	X							
1		3/8" stem nut				X				
1		1/4" stem nut	X	X	X			X		

* Letter stamped on the component.

The performances stated in this sheet can be modified without any prior notice.

